

Installation and operation instruction

Safety precautions

Explanation of symbols



DANGER

Refers to potentially dangerous situation that may cause serious injury or death.



NOTICE

Refers to potentially dangerous situation that may cause injury or property losses.



FORBID

Refers to the forbidden to do.



MUST OBEY Refers to obey the rules.




NOTICE


The supplier shall not be liable for any loss arising from the failure to comply with the following regulations:

- 1.This equipment is electric appliance, please do not be installed at the place where can easily be splashed with water or high temperature.
- 2.This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- 3.Children shall not play with the appliance.
- 4.Cleaning and maintenance shall not be made by children without supervision.

Unit:mm



Overview






Notice





The pictures of this instruction are for reference only. Please subject to the actual product.

Installation

Parts List







 <p>The controller</p>	 <p>Instruction</p>	 <p>Expansion nuts and screws</p>
---	--	--



Tools

 <p>Drill</p>	 <p>Drill bit dia.5mm</p>	 <p>Cross screwdriver</p>	 <p>Pen</p>
--	--	--	--

Installation Mode A






On the wall





Installation Mode B

On the floor



Operation

Button operation

- In the status of the bidet being seated,

By press anywhere on the cover of the controller by hand or foot, the bidet will start rear washing which lasts for 90 seconds, then automatically start drying which lasts for 180 seconds, and then automatically stop.


During rear washing, if press again the cover of the controller, the bidet will start drying for 180 seconds and then automatically stop.

During rear washing, if wave hand to shortly cover the infrared window, the bidet will start the "Infrared sensor operation" .

During drying, if press again the cover of the controller, the drying will stop.

During drying, if wave hand to shortly cover the infrared window, the drying will stop.

During washing, if keep pressing the cover of the controller more than 2 seconds, the washing will stop.



Notice: the pressing weight on the cover of the controller shall not be more than 100kg.

Infrared sensor operation

- In the status of the bidet being seated,

By waving hand to shortly cover the infrared window, the bidet will start female washing which lasts for 30 seconds, then automatically start drying which lasts for 180 seconds, and then automatically stop.

During female washing, if wave hand again to shortly cover the infrared window, the bidet will start drying for 180 seconds and then automatically stop.


During female washing, if press the cover of the controller, the bidet will start the "Button operation".

During drying, if press the cover of the controller, the drying will stop.

During drying, if wave hand again to shortly cover the infrared window, the drying will stop.

During washing, if keep covering the infrared window more than 2 seconds, the washing will stop.

Infrared
window



Operation

Open or close infrared sensor


Shortly press once the Setup button **【P】** to open or close the infrared sensor:

If the indicator light is on for 3 seconds, the infrared sensor is open.

If the indicator light quickly flashes 6 times, the infrared sensor is closed.

After above setup and no other operation, when the indicator light further quickly flashes 3 times, the setup is saved and exist automatically.

【P】 Setup button




Pairing with original remote control

Shortly and continuously press twice the Setup button **【P】** , it's in the pairing status, with the indicator light slowly flashing, then press the Stop button on the original remote control of the bidet. The setup will be saved with indicator light quickly flashing 3 times and exist automatically.

During the pairing status while no further operation, it will exist automatically after 10 seconds.

【P】 Setup button



Operation

Learning

●Infrared sensor function learning


Shortly and continuously press three times the Setup button 【P】 , it's in the infrared sensor operation learning status, with the indicator light quickly flashing. Then press the function buttons on original remote control. This controller will automatically learn the same functions. The setup will be saved with indicator light flashing three times and then exist.

During the infrared sensor operation learning status while no further operation, it will exist automatically after 10 seconds.

●Button function learning


Shortly and continuously press three times the Setup button 【P】 , with the indicator light quickly flashing, then shortly press once again the Setup button, with the indicator light always on, and it's in the button function learning status. Then press the function buttons on original remote control. This controller will automatically learn the same functions. The setup will be saved with indicator light flashing three times and then exist.

During the infrared sensor operation learning status while no further operation, it will exist automatically after 10 seconds.



Reset

In the stand by status, keep pressing the Setup button more than 5 seconds. After the indicator light quickly flashes 6 times, it's reset to factory defaults.



Maintenance


Replace batteries

- The controller requires 2 batteries (type 1.5V R3/AAA).
- When the user lights flash continuously, please replace the batteries in time.



NOTICE

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the controller before being charged.
3. Different types of batteries or new and used batteries are not to be mixed.
4. Batteries are to be installed in the correct polarities.
5. The exhausted batteries are to be removed from the controller and safely disposed.
6. If the controller is to be unused for a long period, the batteries should be removed.
7. The supply terminals are not to be short-circuited.



Trouble Shooting

Problems	Potential cause	Suggested action
The controller cannot work	1.Maybe there are not batteries in the controller.	Please install the correct batteries in the controller.
	2.Maybe the battery power is too low (indicator light quickly flashes 10 times continuously).	When the battery power is too low, the indicator light will flash. Please replace the batteries.
	3.Maybe the code of the controller and the original remote control is not the same.	Please pair the code as per instruction "Pairing with original remote control."
	4.The infrared sensor is covered by something or dirt for a long period.	Please remove the covering thing.

Environment protection

Disposal of electrical and electronic appliances

We are committed to protecting the environment. Please dispose this product properly at the end of its lifecycle in a responsible manner to prevent certain substances contained in electrical or electronic appliance from threat to human health and the environment.

This product should not be mixed with general household waste.

Home users should contact the retailer or local government to learn detailed information on how to recycle this product environmentally friendly.

The batteries should be removed in advance and properly sorted for garbage, and discarded in a suitable recycling container.

Date: 2023/12/19
Rev. No. 1.0